

- %@?E&E

TVOeSJT

t]`TReZ_ d/XZ_

†TZ6j

alfi-bada

†dW

genedal


†Sfeè_è_V †è_VXfZUV †SRT\]ZXYe

†IR Xf RXV

gnife

†b**Z**^ V R†U

ReZ_



7 Replacing battery ...

1 INTRODUCTION

2.3.4 Language

In LANGUAGE you choose the language of your Suunto Core user interface (English, German, French or Spanish).

To choose a language:

- 1. In GENERAL, select LANGUAGE.
- 2. Select a language from the list with [+] and [- Light].

2.3.5 Activating button lock

You can activate and deactivate the button lock by keeping [-Light] pressed down. When the button lock is activated, it is indicated with a lock symbol

NOTE: You can change views and use the backlight when the button lock is activated.

- 2. Scroll down to TIME-DATE using [- Light].
- 3. Enter with [Mode].

3.1.1 Setting time

In TIME you set the time.

To set the time:


1. In TIME-DATE, select TIME

Possible real life situation: Knowing the time at home

You are traveling abroad and you set the dual time to be the time at home. The main time is the time at your current location. Now you always know the local time and you can quickly check what time it is at home.

3.1.4 Setting sunrise and sunset times

In SUNRISE



Possible real life situation: Waking up in the morning You want to wake up early tomorrow morning. You set your Suunto Core alarm

4 USING ALTI & BARO MODE

In the ALTI & BARO mode you can view the current altitude, barometric pressure or snorkeling depth. It offers four profiles: AUTOMATIC, ALTIMETER, BAROMETER and DEPTH METER. You can access different views depending on which profile is activated when you are in the ALTI & BARO mode.

4.1 How Alti & Baro works

To get the right readings from ALTI & BARO, it is important to understand how Suunto Core calculates altitude and sea level air pressure.

Suunto Core constantly measures absolute air pressure. Based on this measurement and reference values, it calculates altitude or sea level air pressure.

4.1.1 Getting correct readings

If you are engaged in an outdoor activity that requires you to know the air pressure, you need to enter the altitude reference value for your location. This

- 2. Select PROFILE.
- 3. Choose a suitable profile.

to check upcoming weather conditions. The weather trend indicator is comprised of two lines forming an arrow. Each line represents a 3-hour period. The right line represents the last 3 hours. The left line represents the 3 hours prior to the last 3 hours. So the line can indicate 9 different patterns in the barometric trend.



Situation 3-6 hours ago

Dropped heavy (>2 hPa/3hours)

Remained stable

Situation last 3 hours

Dropping in heavily (>2 hPa/3hours)

Rising heavily (>2 hPa/3hours)

Rose heavy (>2 hPa/3hours)

Dropping heavily (>2 hPa/3hours)

TIP: If the weather trend indicator shows that the air pressure is constantly rising, there is a higher possibility of better weather upcoming. Again, if the air pressure is constantly falling, there is a higher possibility of bad weather.

start to get tired. You check your altitude, and see that there's still a lot of climbing ahead. Maybe you need to rethink your next check point.

4.5.2 Recording logs

Altitude points are recorded according to the recording interval you have chosen.

Τ

A 7-day log of changes in sea level air pressure can be viewed in ALTI-BARO memory in MENU (see 6.1 Alti-baro memory on page 36.)

Possible real life situation: Using the BAROMETER profile

You're still hiking and you're getting tired. You decide to take a nap and you set up your tent. Since your altitude will stay the same for a while, you activate the BAROMETER profile. When you wake up, you will be able to check changes in sea level air pressure with an eye on the weather.

4.6.1 Recording logs

When you are recording logs in the ALTIMETER profile, you can switch to tofile

4.8.1 Recording logs in depth meter profile

The log recorder in the DEPTH METER profile works similarly to the log recorder in the ALTIMETER profile, but instead of recording altitude it records the depth of your snorkeling dives.


To record logs in the DEPTH METER profile:

- 1. In the ALTI & BARO mode, select the log recorder view.
- 2. Start, stop and restart it with [Start Stop]



5 USING COMPASS MODE

You can use the compass in two ways: you can use the bezel or the bearing tracking.



- 3. Choose a log from the list.
- Lock the log by choosing YES (press [- Light])
 OR
 Cancel by choosing No (press [View]).

6.3 Choosing recording interval

You can choose the recording interval in REC INTERVAL in MENU.

You can choose between five recording intervals:

- 1 second
- 5 seconds
- 10 seconds
- 30 seconds
- 60 seconds

When browsing through the intervals, the available recording time is shown in the lower part of the display.

To choose a recording interval:

- 1. In MEMORY, select REC INTERVAL.
- 2. Choose a recording interval using [+] and [- Light].

7 REPLACING BATTERY

Your Suunto Core operates on a 3-volt lithium cell, type: CR 2032.

NOTE: The markings on the cover may be unaligned once the cover has been tightened. This doesn't matter. If the cover is undamaged, it does not need to be replaced.

NOTE: If the threads of the battery compartment cover are damaged, send

8 SPECIFICATIONS

8.1 Technical data

General

Operating temperature -20 °C to +60 °C / -4°F to +140°F Storage temperature -30 °C to +60 °C / -22°F to +140°F Water-resistant 30 m / 100 ft (according to ISO 2281) Mineral glass

Compass

Resolution 1°

8.2 Trademark

Suunto, Wristop Computer, Suunto Core, their logos, and other Suunto brand trademarks and made names are registered or unregistered trademarks of Suunto Oy. All rights are reserved.

8.3 Copyright

Copyright © Suunto Oy 2007. All rights reserved. This publication and its contents are proprietary to Suunto Oy and are intended solely for the use of its clients to obtain knowledge and key information regarding the operation of Suunto Core products. Its contents shall not be used or distributed for any other purpose and/or otherwise communicated, disclosed or reproduced without the prior written consent of Suunto Oy.

Index

Α

alarm,

```
tone guides, 7
units, 6
getting correct readings, 30

I
incorrect readings, 17

L
language, 9
locking logs, 36, 37
logs
```

locking, 36

