

Cal. 5T82

INSTRUCTIONS	(P. 3)
BEDIENUNGSANLEITUNG	(S. 27)
INSTRUCTIONS	(P. 51)
ISTRUZIONI	(P. 75)
INSTRUCCIONES	(P. 99)
INSTRUÇÕES	(P. 123)
	(147)

You are now the proud owner of a SEIKO Analogue Quartz Watch Cal. 5T82. For best results, please read the instructions in this booklet carefully before using your SEIKO Analogue Quartz Watch. Please keep this manual handy for ready reference.

Sie sind jetzt Besitzer einer SEIKO Analog-Quarzuhr Kal. 5T82. Bitte lesen Sie diese Bedienungsanleitung vor Verwendung der Uhr sorgfältig durch und heben Sie sie gut auf.

Vous voici l'heureux propriétaire d'une montre quartz analogique SEIKO Cal. 5T82. Pour obtenir d'excellentes performances de cet article SEIKO, veuillez lire attentivement cette brochure que vous conserverez pour toute référence ultérieure.

Siete ora in possesso di un orologio SEIKO Analogico al Quarzo Cal. 5T82. Per ottenere i migliori possibili risultati dal Vostro orologio, leggere attentamente le istruzioni di questo manuale prima di utilizzare il Vostro orologio SEIKO analogico al quarzo. Conservare poi il manuale stesso per ogni qualsiasi eventuale futuro riferimento.

WORLD TIME

- The time of a selected city is displayed in the 24-hour indication by 2 small hands.

.

If daylight saving time is used in a city on the bezel, an arrow mark is printed to the right of the city marker.

TIME DIFFERENCES

(GMT) = Greenwich Mean Time

(As of February, 2003)

English

GMT ± (hours)	Marking on the bezel/dial		Name of city	Other cities
0				

SINGLE-TIME ALARM

- The alarm can be set to ring only once at a designated time within the coming 12 hours.
- The alarm time can be set in one minute increments.

ALARM TIME SETTING

- ☆ Before using the alarm, check that the ALARM hands are adjusted to the current time. (See “SETTING THE TIME AND ADJUSTING ALARM AND WORLD TIME HANDS”)



CROWN

Pull out to first click.



B

Press repeatedly to set the desired alarm time.



CROWN

● HOW TO STOP THE ALARM

