BSN 8X53-A1604

8X53
HANDY MANUAL

A R T

Printed in Japan

8 Manual time zone selection of the sub-dial

Adjust the sub-dial by selecting the time of the time zone.

ü The sub-dial cannot be adjusted to a time outside the time zone.

9 DST setting of the main-dial

10

11

■

12 When boarding (in-flight mode ( ))

Set to the in-flight mode (

13

SPECIFICATIONS