

i **Eco-Drive function**

This solar powered Eco-Drive watch is powered by photo energy converted into electrical energy.

The date and time can be corrected by changing the position of the crown. Correct by turning the crown while in the given mode.

*

This watch uses a secondary battery to store electrical energy. When the watch is fully charged, it will maintain its accuracy for about 9 months.

<Ensuring best operation of the watch>

To receive the greatest pleasure from your watch, always store it in a sunlit location.

j Placing the watch near a

5. Characteristics of the Solar Powered Watch

When the watch is insufficiently charged, the indication will be changed as follows:

[Normal indication]

[Operation stops]

The watch will stop
due to an insufficient
charging.

<When the watch stopped due to an insufficient charging>

Charge the watch sufficiently, as indicated in “Guide to Charging Time”.

At this time, be sure to charge the watch with sunlight rather than under fluorescent light.

C. Quick Start (models with a second hand only)

If the watch stops due to insufficient charge, the second hand will start moving at 2-second intervals if the watch

Charging time (approxima

**Illuminance
(lx)**

Environment

NO

NO

NO

NO

.

