

C. FUNCTIONS OF SOLAR POWERED WATCH

If the charge becomes insufficient, a warning function will be activated that causes the display to change as shown below.

Refer to the explanations of each function on the following page for further details.

time0 0SaB50 06hLW4f.wd52j/TT4 1 Tf7 0 0 7 525.1

If insufficient charge continues

If insufficiently
charged and
time is set

Recharge by exposing to light

Stop

For correct use within the design limits of the watch, confirm the level of water-

