
INSTRUCTIONS	(P.	3)
BEDIENUNGSANLEITUNG	(S.	24)
INSTRUCTIONS	(P.	46)
ISTRUZIONI	(P.	68)
INSTRUCCIONES	(P.	90)
INSTRUÇÕES	(P.	112)
	(P.	134)
	(156)	

CONTENTS

2

Page



-

* The position or design of the displays may differ depending on the model.

6

English

11

1.

4. Pull out the crown to the second click when the second hand is at the 12 o'clock position. (The second hand stops on the spot.)



English

English