



Thank you for your purchase of this Citizen watch.

Before using the watch, read this instruction manual carefully to ensure correct use.

After reading the manual, store it in a safe place for future reference.

Visit the Citizen website (<http://www.citizenwatch.com>) or contact your retailer for more information. The website also be found on the website.











Recessed buttons





















### **3 Press the crown back into its normal position.**

Be sure to secure if the watch has a screw down crown.  
Water may enter your watch.





**3 P**









## Eco-Drive watch handling precautions

<Always Make Sure to Recharge Frequently>

-













## Precautionary items and usage limitations

---

- Please request adjustment or repair of the band in the following cases:
  - You notice an abnormality with the band due to corrosion.
  -



•





<b>Mvmnt. Cal. No.:</b>	B642
<b>Type</b>	Analog solar-powered watch
<b>Timekeeping accuracy</b>	Within +/-15 seconds per month when worn at normal operating



Model No.CA7 \*

Cal.B642

CTZ-B8195